

# Van/SUV Loading Steps for the Mini-Pro Series



**1**  
Remove forks and lean machine back into van under lift gate.



**2**  
Fold and pin legs so they will clear opening.



**3**  
Load machine using bottom of legs as handles.



**4**  
Add forks into back of van.

## Notes:

- 1.) Use safe lifting practices, including assistance from two or more people if needed.
- 2.) Laying a small piece of plywood into the vehicle may assist as the seat folding handle holes and other contours and features in the back of some passenger van vehicle seats may make it more difficult to push the machine into and out of the vehicle.
- 3.) Loading and unloading should be done on flat level surface - not on an incline. This includes truck bed, van and SUV loading.

The steps above are applicable to the MLM-12 and MLM-16 models. Mini Van and SUV loading of the heavier MLM-20 is not recommended due to the weight of the machine and its longer legs.

